


1 / 7

FIG. 1



2 / 7

FIG. 2

NO.	MODE	SYSTEM STATUS	CLUTCH STATUS	MULTIPLE DISK CLUTCH	DOG CLUTCH FOR SPEED CHANGE	DOG CLUTCH FOR MOTOR GENERATOR	REMARKS
1	STOP	IDLING AND POWER	ON	OFF	N	ON	ENGINE START
2		GENERATING	OFF	OFF	1st	ON	
3	MOTOR GENERATOR RUN	REVERSING	OFF	OFF	1st	ON	REVERSE ROTATION REGENERATING BRAKE
4		LOW SPEED (FIRST)	OFF	OFF	1st	ON	
5		INTERMEDIATE SPEED (SECOND)	OFF	OFF	2nd	ON	
6		HIGH SPEED (THIRD)	OFF	ON	N	ON	
7	ENGINE RUN	LOW SPEED (FIRST)	ON	OFF	1st	OFF	
8			ON	OFF	1st	ON	ASSISTING POWER GENERATION
9		INTERMEDIATE SPEED (SECOND)	ON	OFF	2nd	OFF	
10			ON	OFF	2nd	ON	ASSISTING POWER GENERATION
11		HIGH SPEED (THIRD)	ON	ON	N	OFF	
12			ON	ON	N	ON	ASSISTING POWER GENERATION

3 / 7

FIG. 3






FIG. 4




5 / 7

FIG. 5



6 / 7

FIG. 6



7 / 7

FIG. 7

